




SPOTCLEAN® MINI CORDLESS

4065 SERIES



EN BATTERY REMOVAL INSTRUCTIONS

AR تعليمات إزالة البطارية

BG ИНСТРУКЦИИ ЗА ОТСТРАНЯВАНЕ НА БАТЕРИЯТА

BS UPUTSTVA ZA VAĐENJE BATERIJE

CHS 电池拆卸说明

CHT 電池拆卸指南

CZ POKYNY K VYJMUTÍ BATERIE

DE ANWEISUNGEN ZUR AKKUENTNAHME

DK VEJLEDNING FOR FJERNELSE AF BATTERIET

EL ΟΔΗΓΙΕΣ ΑΦΑΙΡΕΣΗΣ ΜΠΑΤΑΡΙΑΣ

ES INSTRUCCIONES PARA RETIRAR LA BATERÍA

ET PATAREI EEMALDAMISE JUHISED

FI AKUN POISTO-OHJEET

FR INSTRUCTIONS CONCERNANT LE RETRAIT DE LA BATTERIE

HE הוראות להוצאת הסוללה

HR UPUTE ZA UKLANJANJE BATERIJE

HU AKKUMULÁTOR ELTÁVOLÍTÁSI ÚTMUTATÓ

IT ISTRUZIONI PER LA RIMOZIONE DELLA BATTERIA

KO 배터리 분리 방법

LT AKUMULATORIAUS IŠĖMIMO INSTRUKCIJA

LV AKUMULATORA NOŅĒMŠANAS INSTRUKCIJAS

MK УПАТСТВО ЗА ОТСТРАНУВАЊЕ НА БАТЕРИИТЕ

ML ARAHAN MENGALIH KELUAR BATERI

NL INSTRUCTIES VERWIJDEREN ACCU

NO SLIK FJERNER DU BATTERIET

PL INSTRUKCJA DEMONTAŻU AKUMULATORA

PT INSTRUÇÕES DE REMOÇÃO DA BATERIA

RO INSTRUCȚIUNI PENTRU SCOATEREA BATERIEI

RU ИНСТРУКЦИИ ПО ИЗВЛЕЧЕНИЮ БАТАРЕИ

SE INSTRUKTIONER BORTTAGNING AV BATTERIS

SK POKYNY NA VYBRATIE BATÉRIE

SL NAVODILA ZA ODSTRANITEV BATERIJE

SR UPUTSTVO ZA UKLANJANJE BATERIJE

TA பேட்டரியை அகற்றுவதற்கான அறிவுறுத்தல்கள்

TH คำแนะนำการถอดแบตเตอรี่

TR BATARYA ÇIKARMA TALİMATLARI

